

Fish model assembly instructions:

1. Please cut out all the parts into 30 parts in total. Please use diagonal pliers or nail clippers for safer cutting.
2. There is a number on each part, and the parts are divided into five regional parts: A, B, C, D, and E.
3. Assemble the parts in the four areas A, B, C, and D respectively. For the assembly direction sequence, please refer to the assembly diagram. D1~D4 are the fish head parts. A1~A7 are the chest. B1~B6 are the abdomen. C1~C2 are the fish tail.
4. Then use the figure-8 buckle to string together the four area components A, B, C, and D to complete the Maruka fish model.
5. According to the number on the sticker, stick the sticker on the corresponding part to complete the three-dimensional fish puzzle



